




HTC Incredible 2 Micro SD Card Replacement

How to replace your SD memory card.

Written By: Ka Tong




INTRODUCTION

Having memory issues? Replacing the SD memory card is quick and painless.

Step 1 — Back Panel




- Press your thumbnail into the slot between the rear panel and the front casing located on the bottom of the phone. Use a penny or dime if you have trouble using your thumbnail.
 - With a moderate amount of force, pry the rear panel up and away from the phone. You may need to slide your thumbnail up the crack to separate the rear panel from the front casing.
-  This can take a little bit of effort. Don't be discouraged if you can't get it right away.

Step 2



- Remove the rear panel from the phone.

Step 3 — Micro SD Card



- Use your fingertip to push inward on the SD card until you hear a click.

Step 4



- Remove your finger. The SD card is no longer being held in place.
- Grasp it with two fingers and pull it towards you to remove it.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-07-02 06:49:33 AM.